


PRE-WIRE DATA NETWORKING AND INTERNET

with CAT 5e



PRE-WIRE GUIDE

Using Category 5e cable, install the following cable runs from the network enclosure:

- One from each computer location.
- One from any location(s) where a computer peripheral (such as a printer) might be located separately from the computer.
- One at any location where access to the network is desired (kitchen, bedroom, or den).

cable: Category 5e

connectors: jacks and plugs are Category 5e, type RJ-45 (4 pair)

applications: printer sharing, 10 BASE-T (Ethernet) or 100 BASE-T (Fast Ethernet)

COLOR CODING

blue: data